Digital Camera

LCD Display
Viewfinder
Lens Focus Mode Switch
Main Control Dial
Shutter Button
DISP
MENU
JUMP
Erase Button
Play Button
Flash
Cross Keys
ISO
AF
WB
Mode Dial
Power Switch
Canon
Lens Release
Flash Button
Memory Card Slot
Lens
CANON ZOOM LENS EF-S 18-55mm 1:3.5-5.6 II
lens not included
DIGITAL Rebel XTi