Film Camera

Camera Parts

Neck strap eyelet

Depth-of-field preview lever

Lens release button

Exposure meter button

Nikon FM10

Self-timer lever

Hand grip

Shutter speed dial/ISO selector ring

Shutter release button

Frame counter

Film rewind crank/camera back lock lever

Accessory shoe/hot shoe contact

Multiple exposure lever

ISO film speed indicator

Film advance lever